



james
MARTIN
BAKER'S COLLECTION

USE, CARE AND SAFETY ADVICE

Remove Eurohook (assisted by sliding to a corner) and any residual label adhesive. Wash in hot soapy water; rinse and dry before first use. Season the cooking surface with a little oil and wipe with kitchen paper. Stellar Bakeware is not suitable for Microwave oven use. Always use Oven Gloves or similar when moving the bakeware around the oven. Stellar Bakeware is guaranteed for oven use up to 210°C, 410°F, Gas Mark 6. Allow bakeware to cool before plunging into washing water - pouring cold water into hot bakeware may cause warping. If using on the hob low heat settings must be used.

NON STICK SURFACES

Use only nylon or wooden tools as metal tools and harsh abrasives will degrade the Non Stick coatings. Do not cut food with a knife in your bakeware. Take care to avoid scratching Non Stick surfaces when storing.

CLEANING

wash in hot soapy water after every use. Soak and use only nylon scouring pads to remove burnt-on deposits. Dry immediately. Stellar Bakeware is dishwasher safe; however, they should be removed immediately after dishwashing and dried straight away.

STELLAR BAKEWARE GUARANTEE

Please read the Use, Care and Safety Advice thoroughly. Stellar Bakeware has a Lifetime Guarantee to be free from defects in material and workmanship under normal household use. Non Stick coatings are guaranteed for 5 years, providing the Use, Care and Safety Advice is followed.

We promise to the original purchaser that any defective part or item will be replaced, (or we will supply a product of equal value if the product is out of production).

The Guarantee does not cover damage by accident, misuse or commercial use. In addition, discoloration, scratching, staining and damage from overheating is not covered by the guarantee.

This Guarantee is in addition to your statutory rights.

STELLAR

Avonmouth Way
Bristol
BS11 9HX
Great Britain

customerservice@horwood.co.uk

www.stellarcookware.co.uk